

Thank you for purchasing our fun and sleek wind blocker!

When installing your new wind blocker, push down with some force, insuring that the clearance between the bottom of acrylic and panel are no more than 5mm.

Side clips must have a very tight contact with the faux roll bars. If there is a gap between the side clips and the faux roll bars, release the screw on each side clip, but do not remove it, and push clips up to make a more tight fit. Once adjusted, tighten the screws.

Cleaning your acrylic wind blocker:

Simply wipe dust with microfiber cloth.

If necessary, wash with a mild dish detergent and lukewarm water. Use a clean soft cloth, applying light pressure. Rinse with clean water and dry by blotting with a damp cloth or chamois.

DO NOT USE: window cleaners, any upholstery (leather/vinyl) cleaning product, scouring compounds or solvents, such as acetone, gasoline, benzene, carbon tetrachloride, or lacquer thinner on the acrylic.

Enjoy!!

Check for new options at mx5things.com

Post your comments there or at forum.miata.net